



Camaro Running Light Bezel Installation Instructions

Tools Needed: Plastic Flat Head Plier



Step One: Insert rubber flat head into the factory bezel. Make sure to use a **Plastic** Flat head to prevent scratches.



Step Two: Once the flat head is inserted into the bezel, slide prior into factory bezel and create a separation pocket.



Step Three: Slide the flat head around the edges of the factory bezel and use your free hand to gently pull the bezel loose.



Step Four: Pull out the factory bezel once it is free from the vehicle.



Step Five: The Bezel that reads, "Top RH" is for the passenger side of the vehicle, and the bezel that reads "Top LH" is for the driver's side.



Step Six: Align the DefenderWorx Chrome Running Lights Bezel's attachment clips to the inside of the vehicle's crevice.



Step Seven: Insert the DefenderWorx Chrome Running Light Bezel into the crevice. Attachment clips should press firmly into place.



Final Step: Enjoy your new DefenderWorx Chrome Running Light Bezel!

