



AMERICAN CAR CRAFT INSTRUCTIONS

CAMARO CARBON FIBER RS DOORSILLS

PARTS INCLUDED:

 2-Stainless Deluxe Doorsills

 1 Pack of Promotor

PLEASE NOTE THAT THIS IS A PERMANENT INSTALLATION AND THE NEW DOORSILLS CANNOT BE REMOVED WITHOUT DAMAGING THE PART. PLEASE NOTE YOUR CAR WILL NOT BE DAMAGED IN ANY WAY.

Your new doorsills come to you with a protective liner. DO NOT remove the liner until installation is complete.

1. Thoroughly clean the sill area to be mounted first with soap and water then with household rubbing alcohol to remove any and all dirt and waxes. Then swipe the areas once with the adhesive promoter provided. The correct position of the new sill should set centered onto the factory plastic doorsills.
2. Once you are familiar with the correct position of your new doorsills simply peel the red release liner from the back of the new sill plate and carefully place it into position pressing firmly to set. Remove protective liner. Repeat process for opposite side.

Thank you and enjoy your new purchase!

If you have any questions during installation please call American Car Craft at 727 861-1500.