



2013 and Newer Camaro Manual Shift Knob

Fits GM Factory Shifter

INSTALLATION INSTRUCTIONS

Tools Needed:

- Allen Wrench
- 1/16" Allen Wrench

1. Make sure the emergency brake is engaged and the car will not move if put into neutral.
2. While looking down onto the shifter, grab hold of the chrome beauty ring at the bottom of the shift knob (at the top of the shift boot). Pull up to start while turning counter clock-wise. It should rotate about a quarter turn and come down free of the shift knob.
3. On the passenger side of the shift knob, locate the set screw holding the shift knob onto the shift shaft. Loosen this set screw and pull the shift knob off.
4. Take your new shift knob and put it onto the shift shaft (make sure the set screws in this new knob are backed out far enough to allow it to slip completely onto the shift shaft). Align the logo design to read from left to right. Tighten the three set screws in the new shift knob to hold it onto the shift shaft.
5. Attach the chrome beauty ring and boot in the opposite manner from step 2.
6. Wipe clean and enjoy!

AMERICAN BROTHER DESIGNS

www.americanbrotherdesigns.com